




Tontti 23100/37






Tontti 27932/1






Tontti 36223/3




Tontti 36243/3




Tontit 54008/1, 2 ja 3 sekä 54009/1







Tontit 54037/6, 54141/1 ja 54145/1



Tontit 54143/1, 54144/1, 2 ja 3



Tontit 54109/1 ja 2



Tontit 54101/3,4, 54102/1-4, 54103/2-4, 54104/1-7 ja 54105/1-6